



1




2



Push out the plug using the plug lever. During charging, the LED on the charger case and the battery will be lit. LED on battery will shut off when it is fully recharged or unplugged. LED on charger case keeps lighting during recharging.

3



- 1) Screw the cartomizer onto the battery. Now FS812 is ready to be smoked.
- 2) The LED on the tip of the battery will glow when you puff and will flash when you need a recharge. The battery that comes on the device is charged, but not fully so charging your FS812 before using.
- 3) 280mAh Battery and 6pcs Mega Cartomizer together in the charger case bring you a fantastic no tobacco smoking life.

NO TOBACCO HEALTHY LIFE
REAL CIGARETTE TASTE AND FEELING

Charger Case
Electronic
Cigarette

Warning: FS812 must be used by persons of legal smoking age according to the local law. FS812 contains nicotine and flavoring that is extracted from tobacco along with other ingredients that may be harmful to your health. FS812 should not be used by non-smokers, women who are pregnant or nursing, those sensitive to nicotine, or persons with or at risk of heart disease, high blood pressure, diabetes, or taking medicine for depression or asthma. FS812 is not a smoking cessation product and is not to be used as such. Please keep FS812 out of reach of children and pets.

Model Number: FS812
Input: 100 – 240V ~ 50/60Hz
Output/Battery: DC 5V / 3.7V 280mAh
Dimension: 101 x 54.5 x 21.5 mm
Weight: 105g

